
How to Upgrade an AT91M40400-based System to an AT91M40800-based System

Background

The AT91M40400 and the AT91M40800 are both members of the Atmel AT91 16/32-bit microcontroller family, which is based on the ARM7TDMI™ processor core. Their main differences are that the AT91F40400 has 4K bytes of internal SRAM and the AT91F40800 has 8K bytes of internal SRAM.

The following paragraphs outline the hardware and software operations to perform when a user would like to upgrade an AT91M40400-based system to an AT91M40800-based system.

Hardware Requirements

Microcontroller Replacement

The user must first replace the microcontroller IC. The AT91M40400 and the AT91M40800 are pin-to-pin compatible and both are packaged in 100-lead TQFP package. The user needs to install the AT91M40800 in place of the AT91M40400.

Internal Pull-up

The AT91M40400 has an internal pull-up resistor on the NRST input pin. This internal pull-up is not present in the AT91M40800. The user should verify whether an external pull-up resistor of 100kΩ on the NRST pin needs to be added.

Note Regarding 5V-tolerant I/O Lines

The AT91M40400 (rev. C) and the AT91M40800 have 5V-tolerant I/Os.

Warning Concerning First Access after a Reset

The AT91M40400 performs the first access to the memory bank connected to NCS0 10 clock cycles after the rising edge of the NRST signal. This period has been increased to 80 clock cycles on the AT91M40800 in order to conform to increased reset time requirements for nonvolatile memories containing the boot code.



**AT91 ARM®
Thumb®
Microcontrollers**

Application Note



Software Requirements

As the core, the architecture and the peripherals of both the AT91M40400 and the AT91M40800 are all compatible, any program written for an AT91M40400-based system can run as is on the same system built with an AT91M40800.

Internal Memory Increase

The AT91M40800 internal memory size is greater than the AT91M40400. If a program has stacks allocated in internal memory, the stack start addresses can be increased from 0x1000 to 0x2000.

Power Management and Clock Controller

The AT91M40800 presents an additional power management feature: peripheral clocks can be enabled and disabled individually. This feature optimizes system power consumption depending on the application phase.

Because the AT91M40800 Power Management Controller defaults after reset to the state when all peripheral clocks are enabled, the code written for the AT91M40400 is compatible with the AT91M40800.



Atmel Headquarters

Corporate Headquarters
2325 Orchard Parkway
San Jose, CA 95131
TEL (408) 441-0311
FAX (408) 487-2600

Europe

Atmel SarL
Route des Arsenaux 41
Casa Postale 80
CH-1705 Fribourg
Switzerland
TEL (41) 26-426-5555
FAX (41) 26-426-5500

Asia

Atmel Asia, Ltd.
Room 1219
Chinachem Golden Plaza
77 Mody Road Tsimhatsui
East Kowloon
Hong Kong
TEL (852) 2721-9778
FAX (852) 2722-1369

Japan

Atmel Japan K.K.
9F, Tonetsu Shinkawa Bldg.
1-24-8 Shinkawa
Chuo-ku, Tokyo 104-0033
Japan
TEL (81) 3-3523-3551
FAX (81) 3-3523-7581

Atmel Operations

Atmel Colorado Springs
1150 E. Cheyenne Mtn. Blvd.
Colorado Springs, CO 80906
TEL (719) 576-3300
FAX (719) 540-1759

Atmel Rousset
Zone Industrielle
13106 Rousset Cedex
France
TEL (33) 4-4253-6000
FAX (33) 4-4253-6001

Atmel Smart Card ICs
Scottish Enterprise Technology Park
East Kilbride, Scotland G75 0QR
TEL (44) 1355-803-000
FAX (44) 1355-242-743

Atmel Grenoble
Avenue de Rochepleine
BP 123
38521 Saint-Egreve Cedex
France
TEL (33) 4-7658-3000
FAX (33) 4-7658-3480

Fax-on-Demand

North America:
1-(800) 292-8635
International:
1-(408) 441-0732

e-mail
literature@atmel.com

Web Site
<http://www.atmel.com>

BBS
1-(408) 436-4309



© Atmel Corporation 2000.

Atmel Corporation makes no warranty for the use of its products, other than those expressly contained in the Company's standard warranty which is detailed in Atmel's Terms and Conditions located on the Company's web site. The Company assumes no responsibility for any errors which may appear in this document, reserves the right to change devices or specifications detailed herein at any time without notice, and does not make any commitment to update the information contained herein. No licenses to patents or other intellectual property of Atmel are granted by the Company in connection with the sale of Atmel products, expressly or by implication. Atmel's products are not authorized for use as critical components in life support devices or systems.

ARM, Thumb and ARM Powered are registered trademarks of ARM Limited.
Marks bearing ® and/or ™ are registered trademarks and trademarks of Atmel Corporation.
Terms and product names in this document may be trademarks of others.



Printed on recycled paper.