

|               |       |
|---------------|-------|
| 標準音高 =        | 60    |
| sample rate = | 16842 |

play sample rate = 4000 ~ 100000Hz

|       |       |       |       |       |       |       |        |        |        |        |        |
|-------|-------|-------|-------|-------|-------|-------|--------|--------|--------|--------|--------|
| 36    | 37    | 38    | 39    | 40    | 41    | 42    | 43     | 44     | 45     | 46     | 47     |
| 4211  | 4461  | 4726  | 5007  | 5305  | 5620  | 5955  | 6309   | 6684   | 7081   | 7502   | 7948   |
|       |       |       |       |       |       |       |        |        |        |        |        |
| 48    | 49    | 50    | 51    | 52    | 53    | 54    | 55     | 56     | 57     | 58     | 59     |
| 8421  | 8922  | 9452  | 10014 | 10610 | 11241 | 11909 | 12617  | 13368  | 14162  | 15005  | 15897  |
|       |       |       |       |       |       |       |        |        |        |        |        |
| 60    | 61    | 62    | 63    | 64    | 65    | 66    | 67     | 68     | 69     | 70     | 71     |
| 16842 | 17843 | 18905 | 20029 | 21220 | 22481 | 23818 | 25234  | 26735  | 28325  | 30009  | 31793  |
|       |       |       |       |       |       |       |        |        |        |        |        |
| 72    | 73    | 74    | 75    | 76    | 77    | 78    | 79     | 80     | 81     | 82     | 83     |
| 33684 | 35687 | 37809 | 40057 | 42439 | 44963 | 47636 | 50469  | 53470  | 56650  | 60018  | 63587  |
|       |       |       |       |       |       |       |        |        |        |        |        |
| 84    | 85    | 86    | 87    | 88    | 89    | 90    | 91     | 92     | 93     | 94     | 95     |
| 67368 | 71374 | 75618 | 80115 | 84878 | 89925 | 95273 | 100938 | 106940 | 113299 | 120036 | 127174 |