

R2A20104/114 Series

Continuous Conduction Mode Interleaving PFC Control IC

R03DS0008EJ0301 Rev.3.01 Jan 08, 2016

Description

R2A20104/114 series is a boost converter control IC with PFC (Power Factor Correction). Employing continuous conduction mode interleaving PFC, it performs higher efficiency and lower switching noise even for high power use. The control of continuous conduction mode is carried out by detecting the current in power MOSFET. The R2A20114 series supports two types of current detection methods; current detection by current transformers (R2A20104SP/FP), and that by shunt resisters (R2A20114SP/FP). So that, it can be applicable for a variety of applications. Interleaving control of the boost converters, namely, producing 180 degrees phase shift between the output signals (GD1,2) driving the boost converters, enables the system to perform high conversion efficiency and low switching noises and, at the same time, to reduces ripple currents in input and output current and then this allows use of smaller components such as boost inductors, input filters and output capacitors. R2A20114 series integrates a various kinds of protection circuits, such as the detection circuit of breaking of wire in feedback loop, two modes of over voltage protection circuits, over current protection circuit and error output circuit (*1), which improve the reliability of the power supply system and reduce the number of component parts on the system.

Features

- Maximum Ratings
 - Supply voltage Vcc: 24 V
 - Junction temperature Tj: from –40 to +150 degrees centigrade
- Electrical characteristics
 - VFB feedback voltage VREF: 2.5 V ± 1.5%
 - UVLO (Undervoltage Lockout) operation start voltage VH: $10.4 \text{ V} \pm 0.7 \text{ V}$
 - UVLO operation shutdown voltage VL: 8.9 V \pm 0.5 V
 - UVLO hysteresis voltage Hysuvl : 1.5 V \pm 0.5 V
- Functions
 - Boost converter control with continuous conduction mode
 - Interleaving control
 - Frequency modulation (*2)
 - Brownout
 - Phase drop (*1)
 - External clock synchronization input
 - External clock synchronization output (*1)
 - Two modes of over voltage protections
 - Mode 1: Dynamic OVP preventing over voltage after sudden variation of load.
 - Mode 2: Static OVP preventing over voltage in the period of normal operation.
 - Feedback loop wire breaking/open detector
 - Dual over voltage protection circuits (*1): FB and OVP2 terminals
 - Current balance control
 - Phase 1 and Phase 2 independent over current protection
 - Package line-up

Pb-free LQFP-40 (R2A20104FP, R2A20114FP)

Pb-free SOP-20 (R2A20104SP, R2A20114SP)


Notes: *1 Supported only by R2A20104FP and R2A20114FP

*2 Frequency modulation periods (dfm) of R2A20104SP and R2A20114SP are fixed.

The Function List of R2A20104/114 Series

Ite	m	R2A20104SP	R2A20104FP	R2A20114SP	R2A20114FP			
PFC control		Continuous conduction mode interleaving						
Current detection meth	nod	Current transformer	•	Shunt resistor				
Package		SOP-20	LQFP-40	SOP-20	LQFP-40			
Protection circuits	Brownout detection	Supported	Supported	Supported	Supported			
	2nd OVP	Not supported	Supported Not supported		Supported			
	Phase error	Not supported	Supported	Not supported	Supported			
Noise reduction	Jitter generation	Supported	Supported	Supported	Supported			
	(Frequency	(But, frequency		(But, frequency				
	modulation)	modulation period		modulation period				
		(dfm)(*1) is fixed)		(dfm)(*1) is fixed)				
Synchronization with	Input	Supported	Supported	Supported	Supported			
external signal	Output	Not supported	Supported	Not supported	Supported			
Efficiency Phase drop		Not supported Supported		Not supported Supported				
improvement								

Note: *1 Refer to the figure depicted below:




Ordering Information

			Package	Taping Abbreviation	
Part No.	Package Name	Package Code	Abbreviation	(Quantity)	Remarks
R2A20104FPW0	FP-40EV	PLQP0040JB-C	FP	W (2000 pcs/reel)	non-HF
R2A20104FPW5					HF
R2A20114FPW0					non-HF
R2A20114FPW5					HF
R2A20104SPW0	FP-20DAV	PRSP0020DD-B	SP	W (2000 pcs/reel)	non-HF
R2A20104SPW5					HF
R2A20114SPW0					non-HF
R2A20114SPW5					HF

Note: HF: Halogen-Free


Pin Arrangement of R2A20104FP and R2A20114FP



Pin Functions of R2A20104FP and R2A20114FP

Pin No.	Pin Name	Input/Output	Function
1	FMR	Input	Frequency modulation setting resistor connecting terminal
2	FMC	Input	Frequency modulation setting capacitor connecting terminal
3	VREF	Output	Reference voltage output terminal
4	ВО	Input	Brownout input terminal
5	VAC	Input	AC voltage input terminal
6	PD	Input	Phase drop input terminal
7	AGND	_	Analog ground
8	E-DELAY	Input	Delay of the Error signal setting terminal
9, 10	N.C.	_	Open
11	ERROR	Output	Error output terminal
12	OFF	Input	Shutdown terminal (VCC Reset)
13	RS	Input	Current correction setting resistor connecting terminal
14	SS	Input	Soft start setting capacitor connecting terminal
15	COMP	Output	Error amplifier output terminal (to be phase-compensated)
16	N.C.		Open
17	FB	Input	Error amplifier input terminal (feedback voltage input terminal)
18	QVP2	Input	OVP2 input terminal
19-21	N.C.	_	Open
22	IRAMP	Input	Ramp waveform setting resistor connecting terminal
23	CSO2	Output	Current sense amplifier 2 output terminal (to be phase-compensated)
24	CSO1	Output	Current sense amplifier 1 output terminal (to be phase-compensated)
25	CS2	Input	Current sense 2 input terminal
26	CS1	Input	Current sense 1 input terminal
27	N.C.	_	Open
28	VCC	Input	Supply voltage terminal
29-31	N.C.	_	Open
32	GD2	Output	Converter 2 Power MOSFET drive terminal
33	PGND		Power ground
34	GD1	Output	Converter 1 Power MOSFET drive terminal
35	N.C.	_	Open
36	SYNC-O	Output	Synchronization signal output terminal
37	RT/SYNC	Input	Frequency setting resistor connecting terminal / Sync. Signal input terminal
38	CT	Input	Frequency setting capacitor connecting terminal
39, 40	N.C.	_	Open


Pin Arrangement of R2A20104SP and R2A20114SP




Pin Functions of R2A20104SP and R2A20114SP

Pin No.	Pin Name	Input/Output	Function
1	RT/SYNC	Input	Frequency setting timing resistor connecting terminal / Sync. signal input terminal
2	CT	Input	Frequency setting timing capacitor connecting terminal
3	FM	Input	Frequency modulation setting timing capacitor connecting terminal
4	VREF	Output	Reference voltage output terminal
5	ВО	Input	Brownout input terminal
6	VAC	Input	AC voltage input terminal
7	AGND	_	Analog ground
8	RS	Input	Current correction setting resistor connecting terminal
9	SS	Input	Soft start setting capacitor connecting terminal
10	COMP	Output	Error amplifier output terminal (to be phase-compensated)
11	FB	Input	Error amplifier input terminal (feedback voltage input terminal)
12	IRAMP	Input	Ramp waveform setting resistor connecting terminal
13	CSO2	Output	Current sense amplifier 2 output terminal (to be phase-compensated)
14	CSO1	Output	Current sense amplifier Output 1 output terminal (to be phase-compensated)
15	CS2	Input	Current sense 2 input terminal
16	CS1	Input	Current sense 1 input terminal
17	VCC	Input	Supply voltage terminal
18	GD2	Output	Converter 2 Power MOSFET drive terminal
19	PGND	_	Power ground
20	GD1	Output	Converter 1 Power MOSFET drive terminal

Block Diagram of R2A20104FP and R2A20114FP



Block Diagram of R2A20104SP and R2A20114SP



Absolute Maximum Ratings

Item		Symbol	Value	Unit	Note	
Supply voltage		VCC	-0.3 to +24	V	3	
GD1 and 2	Peak current	lpk-gd1, lpk-gd2	±1	А	3, 4	
	DC current	ldc-gd1, ldc-gd2	±0.1	А	3	
Vref terminal current		Iref	– 5	mA	3	
Terminal current		It-group	±1	mA	3, 5	
RS terminal current		Irs	-500	μΑ	3	
RT terminal current	RT terminal current		-200	μΑ	3	
RAMP terminal current	RAMP terminal current		-200	μΑ	3	
BO clamp current		lbo	300	μΑ	3	
Terminal voltage		Vt-group	-0.3 to Vref	V	3, 6	
Vref terminal voltage		Vt-ref	-0.3 to Vref+0.3	V	3	
SS terminal voltage		Vt-ss	-0.3 to Vref+1	V	3	
Power dissipation		Pt	1	W	3, 7	
Operating ambient temperature		Ta-opr	-40 to +125	°C		
Junction temperature		Tj	-40 to +150	°C	8	
Storage temperature		Tstg	-55 to +150	°C		

Notes: 1. Rated voltages are with reference to the AGND and PGND terminal.

- 2. For the direction of Rated currents, (+) denotes the current flowing into the IC, and (–) denotes the current flowing out of the IC.
- 3. Ambience temperature, Ta is 25 degrees centigrade.
- 4. Transient current when driving a capacitive load.
- 5. Rated currents of the terminals listed below: COMP, CSO1, CSO2
- 6. Rated voltages of the terminals listed below:

in the case of R2A20104FP/R2A20114FP: CS1, CS2, VAC, RS, FB, PD, BO, ERROR, E-DLAY, OFF,

OVP2, FMC, FMR, RT/SYNC, IRAMP, SYNC-O, CT, COMP,

CSO1, CSO2

in the case of R2A20104SP/R2A20114SP: CS1, CS2, VAC, RS, FB, BO, IRAMP, FM, RT/SYNC, CT,

COMP, CSO1, CSO2

7. Thermal resistor

in the case of R2A20104FP/R2A20114FP: θja = 85.3 degrees centigrade/W

in the case of R2A20104SP/R2A20114SP: θ ja = 120 degrees centigrade/W

These values are obtained under the condition that the IC is mounted on the glass epoxy board, of which size is $50 \times 50 \times 1.6$ [mm] and wiring density is 10%.

8. Stresses exceeding the absolute maximum ratings may damage the device.

These are stress ratings only. Functional operation above the recommended operating ambient temperature range is not implied.

Extended exposure to stresses above the absolute maximum ratings may affect device reliability.


Electrical Characteristics

 $(Ta = 25 ^{\circ}C, \ VCC = 12 \ V, \ CT = 1000 \ pF, \ RT = 27 \ k\Omega, \ CS1, \ CS2 = GND, \ IRAMP = 10 \ k\Omega, \ BO = 1 \ V, \ VAC = 0 \ V, \ RS = 220 \ k\Omega, \ FMC = GND \ (*^1), \ FM = GND \ (*^2), \ FB = COMP)$

	Item	Symbol	Min	Тур	Max	Unit	Test Conditions
Supply	UVLO turn-on threshold	Vuvlh	9.7	10.4	11.1	V	
	UVLO turn-off threshold	VuvII	8.4	8.9	9.4	V	
	UVLO hysteresis	Hysuvl	1.0	1.5	2.0	V	
	Standby current	Istby	_	100	160	μΑ	VCC = 8.9 V
	Operating current	Icc	_	5	7.5	mA	
VREF	Output voltage	Vref	4.85	5.00	5.15	V	Isource = -1 mA
	Line regulation	Vref-line	_	5	20	mV	Isource = -1 mA,
							VCC = 10 V to 24 V
	Load regulation	Vref-load	_	5	20	mV	Isource = -1 mA to -5 mA
	Temperature stability	dVref	_	±80	_	ppm/°C	Ta = -40 to 125°C (*3)
Error	Feedback voltage	Vfb	2.462	2.500	2.538	V	FB-COMP Short
amplifier	Input bias current	Ifb	-0.8	-0.5	-0.2	μА	Measured pin: FB
	Open loop gain	Av	_	40	_	dB	(*3)
	Upper clamp voltage	Vclamp-comp	3.8	4.0	4.3	V	FB = 2.0 V, COMP: Open
	Low voltage	VI-comp	0.0	0.1	0.3	V	FB = 3.0 V, COMP: Open
	Source current	Isrc-comp	-190	-135	-80	μА	FB = 1.5 V, COMP = 2.5 V
	Sink current 1	Isnk-comp1	_	120	_	μΑ	(*3)
	Sink current 2	Isnk-comp2	220	320	420	μΑ	FB =3.5 V, COMP = 2.5 V
	Transconductance	gm	120	200	290	μs	FB = 2.45 V ↔ 2.55 V,
							COMP = 2.5 V
Brownout	PFC enable voltage	Von-pfc	0.74	0.82	0.9	V	Input pin: BO
	PFC disable voltage	Voff-pfc	0.73	0.81	0.89	V	Input pin: BO
Oscillator	Initial accuracy	fout	70	78	86	kHz	Measured pin: OUT, FMC = 0 V
	fout temperature stability	dfout/dTa	_	±0.1	_	%/°C	Ta = -40 to 125°C (*3)
	fout voltage stability	fout-line	-1.5	0.5	1.5	%	VCC = 12 V to 18 V
	CT top voltage	Vct-H	_	3.6	4.0	V	(*3)
	RT voltage	Vrt	1.15	1.25	1.35	V	
	FMC sink current (*1)/	Isnk-fmc (*1)/	6	11	16	μΑ	FMC = 1 V (*1)/
	FM sink current (*2)	Isnk-fm (*2)					FM = 1 V (*2)
	FMC source current (*1)/	Iso-fmc (*1)/	-16.5	-11.5	-6.5	μΑ	FMC = 1 V (*1)/
	FM source current (*2)	Iso-fm (*2)					FM = 1 V (*2)
	FM magnitude change	dfm	19	24	29	kHz	FMC = 5 V (*1)/FM = 5 V (*2) (*3, *4)
	FM frequency 1 (*1)	ffm1	0.25	0.38	0.5	kHz	FMC = 6.8 nF, FMR = 4 V (*4)
	FM frequency 2 (*1)	ffm2	14	25	35	kHz	FM = 220 pF, FMR = 1.2 V (*4)
	FM frequency (*2)	ffm	6	10	14	kHz	FMC = 220 pF (*4)
	1 / / /	ı			1	l	' ' /

Notes: *1 Applied to R2A20104FP, R2A20114FP

- *2 Applied to R2A20104SP, R2A20114SP
- *3 Design Specification (Reference data)
- *4 Refer to the figure shown below:



Electrical Characteristics (cont.)

 $(Ta = 25^{\circ}C, VCC = 12 \text{ V}, CT = 1000 \text{ pF}, RT = 27 \text{ k}\Omega, CS1, CS2 = GND, IRAMP = 10 \text{ k}\Omega, BO = 1 \text{ V}, VAC = 0 \text{ V}, RS = 220 \text{ k}\Omega, FMC = GND (*1), FM = GND (*2), FB = COMP)$

Item		Symbol	Min	Тур	Max	Unit	Test Conditions
Synchroni- zation	SYNC threshold voltage (rising)	Vsync	2.0	2.5	3.0	V	
	SYNC Min. pulse	Psync	2	_	_	μs	
	SYNC-OUT shunt current (*1)	Isync-s	5.0	_	_	mA	
	SYNC-OUT leakage current (*1)	Isync-I	_	_	1.0	μА	
Current	RS output voltage 1	Vrs1	0.56	0.65	0.74	V	VAC = 0 V, VFB = 2.5 V
slope	RS output voltage 2	Vrs2	0.04	0.14	0.26	V	VAC = 2.5 V, VFB = 0 V
	VAC bias current	Ivac	-0.4	-0.2	-0.05	μΑ	Measured pin: VAC
Soft start	Source current	Iss	-40	-28	-16	μA	SS = 2 V
Phase drop	Phase drop threshold voltage (*1)	Vpd	2.4	2.5	2.6	V	
	Phase drop hysteresis (*1)	Hya-pd	150	200	250	mV	
	PD bias current (*1)	lpd	0.05	0.2	0.5	μА	Measured pin: PD
AMP1, 2	CSO offset voltage1 (*5)	Voffset	0.68	0.88	1.0	V	Vcs = 0 V
	CSO offset voltage1 (*6)	Voffset	0.54	0.74	0.86	V	Vcs = 0 V
	CSO offset voltage2	Vcaoh	2.83	3	3.17	V	Vcs = 0.24 V (* ⁵), Vcs = 2.3 V (* ⁶)
	CS Bias current (*5)	lcs-r	-0.4	-0.2	-0.05	μΑ	Measured pin: CS1, 2
	CS Bias current (*6)	lcs-ct	-1.1	-0.8	-0.5	μΑ	Measured pin: CS1, 2
Gate drive	Gate drive rise time	tr-gd	_	30	100	ns	CL = 500 pF
1, 2	Gate drive fall time	tf-gd	_	30	100	ns	CL = 500 pF
	Gate drive low voltage	Vol1-gd	_	0.05	0.2	V	Isink = 10 mA
		Vol2-gd	_	1	1.25	V	Isink = 0.25 mA, VCC = 5 V
	Gate drive high voltage	Voh-gd	11.5	11.9	_	V	Isource = -10 mA
	Minimum duty cycle	Dmin-out	_	_	0	%	
	Maximum duty cycle	Dmax-out	90	95	98	%	
Over	Dynamic OVP Threshold	Vdovp	VFB×	VFB×	VFB×	V	
voltage	voltage		1.025	1.040	1.055		
protection	Static OVP Threshold voltage	Vsovp	VFB× 1.065	VFB× 1.080	VFB× 1.095	V	COMP = OPEN
	Static OVP Hysteresis	Hys-sovp	30	80	130	mV	COMP = OPEN
	OVP2 Threshold voltage (*1)	Vovp2	VFB× 1.065	VFB× 1.080	VFB× 1.095	μА	
	OVP2 Hysteresis (*1)	Hys-ovp2	30	80	130	mV	COMP = OPEN
	OVP2 Bias current (*1)	lovp2	-0.5	-0.3	-0.05	μА	Measured pin: OVP2
	FB Open Detect Threshold voltage	Vfbopen	0.45	0.5	0.55	V	·
	FB Open Detect hysteresis	Vfbopen	0.16	0.2	0.24	V	
Over	OCP Threshold voltage (*5)	VCL	0.28	0.31	0.34	V	
current	OCP Threshold voltage (*6)	VCL	2.9	3	3.1	V	
protection	Delay to output	td-CL		100	250	ns	

Notes: *1 Applied to R2A20104FP, R2A20114FP

^{*2} Applied to R2A20104SP, R2A20114SP

^{*5} Applied to R2A20114FP, R2A20114SP

^{*6} Applied to R2A20104FP, R2A20104SP


Electrical Characteristics (cont.)

 $(Ta = 25^{\circ}C, VCC = 12 \text{ V}, CT = 1000 \text{ pF}, RT = 27 \text{ k}\Omega, CS1, CS2 = GND, IRAMP = 10 \text{ k}\Omega, BO = 1 \text{ V}, VAC = 0 \text{ V}, RS = 220 \text{ k}\Omega, FMC = GND (*1), FM = GND (*2), FB = COMP)$

Item		Symbol	Min	Тур	Max	Unit	Test Conditions
Error signal	ERROR shunt current (*1)	lerror-s	5.0	_	_	mA	
	ERROR leakage current (*1)	lerror-l	_	_	1.0	μΑ	
	Phase error detect point	Perror	1.1	1.35	1.6	_	Vcso1 or 2 = 2.5 V,
							Vcso2 or 1: sweep (*7)
	OFF threshold voltage (*1)	Voff	3.3	4.0	4.7	V	
	E-DELAY charge current (*1)	led-c	-55	-36	-20	μΑ	
	E-DELAY discharge current	led-d	20	36	55	μΑ	
	(*1)						
	E-DELAY threshold voltage	Vdelay	2.35	2.45	2.55	V	
	(*1)						

Notes: *1 Applied to R2A20104FP, R2A20114FP


- *2 Applied to R2A20104SP, R2A20114SP
- *7 Refer to the figure shown below:




$$Perror = \frac{V'cso1(or\ 2)[V] - 0.55[V]}{Vcso2(or\ 1)[V] - 0.55[V]}$$

Package Dimensions

• R2A20104FP and R2A20114FP



R2A20104SP and R2A20114SP



Notice

- 1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information
- 2. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein
- 3. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or
- 4. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from such alteration, modification, copy or otherwise misappropriation of Renesas Electronics product.
- 5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The recommended applications for each Renesas Electronics product depends on

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; and safety equipment etc.

Renesas Electronics products are neither intended nor authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems, surgical implantations etc.), or may cause serious property damages (nuclear reactor control systems, military equipment etc.). You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application for which it is not intended. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for which the product is not intended by Renesas Electronics.

- 6. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges
- 7. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, lease evaluate the safety of the final products or systems manufactured by you
- 8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- 9. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You should not use Renesas Electronics products or technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. When exporting the Renesas Electronics products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations
- 10. It is the responsibility of the buyer or distributor of Renesas Electronics products, who distributes, disposes of, or otherwise places the product with a third party, to notify such third party in advance of the contents and conditions set forth in this document, Renesas Electronics assumes no responsibility for any losses incurred by you or third parties as a result of unauthorized use of Renesas Electronics
- 11. This document may not be reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
- 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics



SALES OFFICES

Renesas Electronics Corporation

http://www.renesas.com

Refer to "http://www.renesas.com/" for the latest and detailed information.

Renesas Electronics America Inc. 2801 Scott Boulevard Santa Clara, CA 95050-2549, U.S.A. Tel: +1-408-588-6000, Fax: +1-408-588-6130

Renesas Electronics Canada Limited 9251 Yonge Street, Suite 8309 Richmond Hill, Ontario Canada L4C 9T3 Tel: +1-905-237-2004

Renesas Electronics Europe Limited

Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K Tel: +44-1628-585-100, Fax: +44-1628-585-900

Renesas Electronics Europe GmbH

Arcadiastrasse 10, 40472 Düsseldorf, German Tel: +49-211-6503-0, Fax: +49-211-6503-1327

Renesas Electronics (China) Co., Ltd. Room 1709, Quantum Plaza. No.27 ZhiChunLu Haidian District, Beijing 100191, P.R.China Tel: +88-10-8235-1155, Fax: +88-10-8235-7679

Renesas Electronics (Shanghai) Co., Ltd.
Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai, P. R. China 200333
Tel: +86-21-2226-0888, Fax: +86-21-2226-0999

Renesas Electronics Hong Kong Limited

Treireads Electronics from Knotig Limited
Unit 1601-1611, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong
Tel: +852-2265-6688, Fax: +852 2886-9022

Renesas Electronics Taiwan Co., Ltd. 13F, No. 363, Fu Shing North Road, Taipei 10543, Taiwan Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

Renesas Electronics Singapore Pte. Ltd. 80 Bendemeer Road, Unit #06-02 Hyllux Innovation Centre, Singapore 339949 Tel: +65-6213-0200, Fax: +65-6213-0300

1207, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia +60-3-7955-9390, Fax: +60-3-7955-9510 Renesas Electronics Malaysia Sdn.Bhd. Unit 1207, Block B. Menara Amcorp, Amco

Renesas Electronics India Pvt. Ltd. No.777C, 100 Feet Road, HAL II Stage, Indiranagar, Bangalore, India Tel: +91-80-67208700, Fax: +91-80-67208777

Renesas Electronics Korea Co., Ltd. 12F., 234 Teheran-ro, Gangnam-Gu, Seoul, 135-080, Korea Tel: +82-2-558-3737, Fax: +82-2-558-5141