January 7, 1998 TEL:805-498-2111 FAX:805-498-3804 WEB:http://www.semtech.com

QUICK REFERENCE DATA

- V_R = 2000V
- I_F = 100mA
- t_{rr} = 200nS
- I_R = 0.25µA

AXIAL LEADED HERMETICALLY SEALED HIGH VOLTAGE FAST RECTIFIER DIODE

- Very low reverse recovery time
- Avalanche capabilities
- Glass passivated for hermetic sealing
- Low switching losses
- Soft, non-snap off, recovery characteristics

ABSOLUTE MAXIMUM RATINGS (@ 25°C unless otherwise specified)

	Symbol	PF20	Unit
Working reverse voltage	V_{RWM}	2000	V
Repetitive reverse voltage	V_{RRM}	2200	V
Average forward current (@ 55°C in oil)	$I_{F(AV)}$	100	mA
Repetitive surge current (@ 55°C)	I_{FRM}	0.5	A
Non-repetitive surge current (t_p = 8.3mS, @ V_R & T_{jmax})	I_{FSM}	1.0	A
Storage temperature range	T_{STG}	-65 to +150	°C
Operating temperature range	T_{OP}	-65 to +150	°C

MECHANICAL



DIM	DIMENSIONS MM MIN	MM MAX	INCHES MIN	INCHES MAX	NOTE
A	-	2.20	-	.087	-
B	32.5	-	1.27	-	-
C	-	3.00	-	.118	-
D	-	.65	-	.026	-

January 7, 1998

CHARACTERISTICS (@ 25°C unless otherwise specified)

	Symbol	PF20	Unit
Average forward current max. (pcb mounted; T_A = 55°C)			
for sine wave	$I_{F(AV)}$	60	mA
for square wave (d = 0.5)	$I_{F(AV)}$	65	mA
Average forward current max. (unstirred oil at 55°C)			
for sine wave	$I_{F(AV)}$	90	mA
for square wave	$I_{F(AV)}$	100	mA
I^2t for fusing (t = 8.3mS) max.	I^2t	0.004	A^2S
Forward voltage drop max. @ I_F = 50mA, T_j = 25°C	V_F	11.0	V
Reverse current max.			
@ V_{RWM}, T_j = 25°C	I_R	0.25	µA
@ V_{RWM}, T_j = 100°C	I_R	3.0	µA
Reverse recovery time max. 50mA I_F to 100mA I_R. Recover to 25mA I_{RR}.	t_{rr}	200	nS
Junction capacitance typ. @ V_R = 5V , f = 1MHz	C_j	1.1	pF
Thermal resistance - junction to oil			
Stirred oil	$R_{\theta JO}$	55	°C/W
Unstirred oil	$R_{\theta JO}$	75	°C/W
Thermal resistance - junction to amb. on 0.06" thick pcb. 1oz copper.	$R_{\theta JA}$	155	°C/W



Fig 1. Junction capacitance against reverse voltage.

January 7, 1998



Fig 2. Forward voltage drop as a function of forward current.



Fig 3. Power derating in air and oil.



Fig 4. Forward power dissipation as a function of forward current, for sinusoidal operation.



Fig 5. Forward power dissipation as a function of forward current, for square wave operation.